

HP Sleeve - INSTALLATION INSTRUCTIONS

Instucciones de instalacion

WHEN INSTALLING OVER NEW OR EXISTING 4"X4" (3.5"X3.5") POST



STEP 1

REMOVE MAILBOX

Borrar buzón



STEP 2

SLIDE VERTICAL SLEEVE

Slide vertical en manga



STEP 3

MEASURE LOCATION 42"

Medir la ubicación 42"



STEP 4

INSTALL MAILBOX MOUNTING PLATE

Instalar la placa de montaje del buzón



STEP 5

INSTALL MAILBOX

Instalar buzón

See these instructions and more at www.thehandypost.com

- Step 1 - If installing a new wood 4"x4" post, we recommend placing it a minimum of 24" in the ground secured by 1 bag of concrete.
- Step 2 - Make sure the wood 4"x4" is **EXACTLY** 42" above ground. Slide the vinyl 4"x4"x42" sleeve over the wood 4"x4". The wood and the vinyl **MUST** both be at 42" above the ground.
- Step 3 - Install your mailbox mounting plate (not included).
- Step 4 - Install your mailbox (not included).

What's in the box: (1) 4"x4"x42" vertical post sleeve, (1) instructions